



FAST FIT HARNESS - GUIDE



IN CABIN ISOLATOR SWITCH

Polarity Sensitive. Ensure layout is as shown..

- 1- Black = Negative/Ground (Gold Pin)
- 2 - Blue Wire - Accessory
- 3- White Wire - 12V Positive



HIGH BEAM CONNECTION

H4 and HB3 Included.
Vehicle Specific Available Separately.

